

Ensure there is enough tubing between the Female QDC attached to the inoculant to reach the Male QDC on the PBR.

Separate this connection and attach to your inoculant

